




DESCRIPTION OF THE DEVICE

1. Dust cover for protecting the magnifying lens
2. Locking screw for adjusting the lamp head
3. Locking screw for adjusting/securing the swivel arm
4. On/off switch
5. Power cord
6. Clamp for attachment to the edge of a table
7. Magnifying lens



TECHNICAL DATA ART. 15406195 | 15406200

Operating voltage	220-240V
Power consumption	10W, 60 LEDs
Lumen	950 lumens
LED service life	Approx. 20.000 hours
Magnifying lens	3D dioptré 5D dioptré
Magnification	1.75x magnification 2.25x magnification
Lens size	Ø19 x 16 cm
Arm length	Approx. 80 cm
Cable length	1.5 metres
Weight	3.9 kg

INTRODUCTION

This operating manual is supplied with the LED magnifying lamp SIRIUS hereinafter referred to as the device, and provides important information on use, safety, connection and operation of the device.

The operating manual must always be kept near the device. It must be read and followed by all persons responsible for operating the device and rectifying faults.

Keep this operating manual and ensure that it accompanies the device if it is passed on to another person.

LIMITATION OF LIABILITY

All technical information, data and information regarding connection and operation correspond to the latest state of knowledge at the time of printing.

No claims may be made on the basis of the information, illustrations or descriptions contained in this manual.

The manufacturer accepts no liability for damage resulting from failure to observe the manual, improper use, incorrect repairs, unauthorised modifications or the use of non-approved spare parts.

INTENDED USE

This device can be used as a desk lamp. With the built-in magnifying lens, the lamp can also be used as a magnifying lamp.

Any other use is considered improper use. No claims may be made for damage caused by using the device for purposes for which it is not intended. The user bears the sole risk.

BASIC SAFETY INSTRUCTIONS

Observe the following safety instructions to ensure safe use of the device:

- Check the device for visible external damage before use. Do not use the device if it is damaged. Risk of electric shock.
- Only have the device repaired by authorised specialist workshops or customer service.
- Incorrectly performed repairs may result in considerable hazards for the user. In addition, all warranty claims will be void.
- If the power cord is damaged, it may only be replaced by an authorised repair technician or customer service in order to avoid hazardous situations.
- Never use the device if the connection cable is defective. Risk of electric shock.
- Do not use extension cables or multi-socket outlets that do not meet the required safety regulations.
- The mains socket must be easily accessible so that the power cord can be unplugged quickly in an emergency.
- The protective cover must always be closed when the lamp is not in use. This protects the lens from damage and prevents a fire hazard caused by light passing through the lens.
- The device must NEVER be placed in a window – there is a risk of fire!
- This device must not be used by persons, including children, with reduced physical, sensory or mental capabilities or with a lack of experience and/or knowledge, unless they are supervised by a responsible person or have been instructed in how to use the device.
- Children must be supervised to ensure that they do not play with the device.
- Do not use optical instruments, such as a magnifying glass, to look directly into the light beam. Risk of eye injury.





INSTALLATION AND CONNECTION

Scope of delivery and transport inspection

The device is supplied as standard with the following components:

- LED magnifying lamp
- Operating manual

UNPACKING

NOTE

- Check that all parts have been supplied and that they show no visible signs of damage.
- If parts are missing or if damage has occurred due to inadequate packaging or transport, please contact the dealer from whom you purchased the device.
- Remove the device and the operating manual from the box.
- Remove all packaging material.

WARNING

Packaging materials must not be used by children as toys.
Risk of suffocation!

DISPOSAL OF PACKAGING

The packaging protects the device against transport damage. The packaging materials have been selected according to environmental compatibility and disposal criteria and can therefore be recycled.

Returning the packaging for recycling saves raw materials and reduces the amount of waste. Dispose of packaging materials that are no longer required in accordance with applicable local regulations.

NOTE

Where possible, keep the original packaging for the device so that it can be packed correctly in the event of a warranty claim.

ELECTRICAL CONNECTION

IMPORTANT

- Compare the device's connection data, voltage and frequency, on the rating plate with the data for your mains power supply. These data must correspond in order to avoid damage to the device.
- Check that the device's power cord (5) is undamaged and is not routed over hot surfaces and/or sharp edges.
- Ensure that the power cord (5) is not pulled tight or broken.
- Do not allow the power cord (5) to hang over corners or edges, as this may present a tripping hazard.
- Insert the mains plug into the socket.

OPERATION AND FUNCTION

Setting up and adjusting the magnifying lamp

- Attach the clamp to a suitable surface, such as the edge of a table.
- Turn the locking screw clockwise until the clamp is securely fastened to the surface.
- Insert the lamp into the clamp holder and adjust the lamp position as required.

Switching on/off

- Set the on/off switch (4) to position "I" to switch on the magnifying lamp.
- Set the on/off switch (4) to position "0" to switch off the magnifying lamp.

Using the magnifying lens

- Remove the protective cover from the magnifying lens by lifting off the dust cover (1).
- Look down through the magnifying lens from above to view small objects enlarged. You can adjust the distance between the magnifying lens and the object to obtain a clearer image.
- **IMPORTANT:** When the magnifying lens is no longer in use, put the dust cover back on.

CLEANING

 **DANGER** Risk of fatal injury due to electric current!

- Unplug the mains plug from the socket before starting cleaning.
- Ensure that no moisture enters the lamp during cleaning.

IMPORTANT: Possible damage to the device!

- Do not use aggressive or abrasive cleaning agents, as these may damage the surfaces of the housing.
- Clean the device only with a slightly damp cloth and a mild washing-up liquid.

MAINTENANCE

The device's light sources consist of long-life LEDs. They cannot be replaced and require no maintenance.

DISPOSAL

- Do not dispose of the device with normal household waste.
- This product is subject to European Directive **2002/96/EC, WEEE, Waste Electrical and Electronic Equipment.**
- Dispose of the device through an approved waste disposal company or at your municipal recycling facility.
- Observe the currently applicable regulations. Contact your local waste disposal authority if in doubt.